NUMERICAL PRICE LIST AND INDEX

FOR

KENT-MOORE SPECIAL SERVICE TOOLS

PRICES EFFECTIVE JUNE 1, 1958—F.O.B. JACKSON, MICHIGAN

All prices subject to change without notice

THIS PRICE LIST SUPERSEDES FORM NO. 56-140-A—EFFECTIVE NOV. 15, 1956

Page Numbers refer to Kent-Moore Service Tool Manual, Form No. 58-1.

Tool No.	Description	Page No.	Suggested Dealer Price
J 129-2	Reamer	4	$ 3.95
J 129-3	J 8003 Reamer	*	3.95
J 134	Depressor	71	4.05
J 136	Press	68	36.85
J 267	Driver	4	2.50
J 269	Guide Remover	4	2.50
J 270-6	Driver Head	o	5.70
J 270-7	Driver Head	o	5.75
J 270-14	Driver Head	*	6.85
J 358-1	Holder	80	6.95
J 452-G	Wheel Puller	*	14.55
J 489	Puller	*	4.95
J 508	Puller	18	1.15
J 510	Gauge	16	.50
J 516	Burnisher	9	7.35
J 526	Service Set	9	18.95
J 540	Remover and Replacer	9	7.95
J 544	Scale	60	5.25
J 553	Puller	68	13.45
J 554	Fixture	70	59.90
J 627	Wrench	71	1.50
J 628	Bleeder	71	.75
J 682	Puller	47	13.20
J 706	Reamer	4	18.80
J 728	Cap Tool	*	2.50
J 736	Puller	70	21.80
J 769	Bearing Installer	o	7.80
J 787	Tool	18	1.10
J 796	Plate Holder	*	†
J 816-1	Screw Driver	18	1.10
J 816-4	Driver	18	1.10
J 816-5	Handle	18	.50
J 818-1	Gauge	16	.50
J 818-2	Gauge	16	.50
J 818-3	Gauge	16	.50
J 818-5	Gauge	16	.50
J 818-6	Gauge	16	.50
J 818-9	Gauge	17	.50
J 818-10	Gauge	17	.50
J 818-11	Gauge	17	.50
J 818-15	Gauge	17	.50
J 820	Puller	47	4.90
J 851	Pins	29	1.25
J 854	Wrench	71	4.95
J 855	Replacer	47	8.95
J 865	Replacer	29-47	8.95
J 870	Wrench	*	13.35
J 918	Puller	*	28.55
J 932	Pliers	*	7.25
J 933	Wrench	29	4.40
J 936	Bearing Remover	29	3.50
J 937	Puller	29	17.05
J 938	Puller	29	24.95
J 941	Replacer	49	7.70
J 943	Remover	56	6.45
J 947	Remover and Replacer	56	31.50
J 962	Puller	47	10.20
J 965-2	Pilot	*	7.70
J 965-3	Reamer	9	19.25
J 966	Gauge	1	8.35
J 968	Driver	47	8.30
J 971	Remover	4	5.35
J 972	Wrench	49	4.85
J 986	Puller	49	16.85
J 994	Replacer	47	5.10
J 995	Driver	1	4.95
J 996	Press Plate	23-49	4.65
J 1032	Wrench	60	4.70
J 1036	Gauge	29	9.45
J 1041	Remover	29	6.35
J 1045	Compressor	1	9.45
J 1048	Gauge	29	9.45
J 1049	Replacer	56	8.00
J 1052	Spreader	67	10.55
J 1089	Driver	4	6.55
J 1090	Driver	4	6.55
J 1126	Pins	29	1.45
J 1130	Remover	29	11.50

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 1135	Gauge	16	.50
J 1137	Bend Iron	18	.90
J 1218	Vise	9	18.50
J 1226	Puller	13	7.95
J 1227-01	Compressor	*	3.75
J 1241-03	Injector Set	*	29.10
J 1242	Timing Gauge	*	1.30
J 1243	Reamer	*	1.90
J 1261	Assembly	*	7.40
J 1262	Puller	62	9.50
J 1264	Wrench	80	17.95
J 1265	Gauge	16	.50
J 1273	Remover	66	2.25
J 1285		*	↑
J 1291-01	Cleaner	*	2.20
J 1293	Assembly Tool	9	5.40
J 1298	Puller	29	24.60
J 1306	Remover	18	.50
J 1308	Gauge	29	4.95
J 1312	Replacer	*	12.10
J 1313	Wrench	80	16.75
J 1315	Wrench	80	17.95
J 1319-02	Gauge	*	39.85
J 1321	Replacer	*	6.95
J 1324	Reamer	70	7.05
J 1328	Press Plate	*	4.25
J 1339	Wrench	79	1.90
J 1340	Wrench	79	3.05
J 1343	Installer	18	.80
J 1354	Installer	31	8.50
J 1357	Driver	49	15.25
J 1359	Expander	*	16.00
J 1364	Driver	*	11.40
J 1388	Gauge	16	.80
J 1389	Adjusting Tool	18	.60
J 1407	Installer	18	.45
J 1411	Socket	49	4.35
J 1429	Replacer	4	11.25
J 1434	Pins	29	2.35
J 1436	Puller	56	15.75
J 1439	Press Plate	*	4.85
J 1440	Press Plate	*	4.25
J 1448	Puller	9	8.15
J 1453-01	Plate	*	6.15
J 1455	Reamer	13	16.95
J 1459	Holder	31	3.75
J 1465	Extension Rod	31	1.75
J 1471	Installer	*	4.80
J 1475	Gauge	16	3.90
J 1488	Driver	*	10.45
J 1503-3A	Handle	18	.50
J 1507	Gauge	29	11.60
J 1508-02	Tool Set	*	22.50
J 1513-01	Removing Set	*	49.75
J 1515	Remover	56	3.75
J 1522	Driver	9	5.95
J 1537	Compressor	31	5.70
J 1561	Wrench	18	1.45
J 1577-01	Gauge Set	16-18	23.85
J 1588	Wrench	75	3.25
J 1589	Wrench	75	3.50
J 1592	Wrench	60	4.95
J 1594	Adapter	60	6.95
J 1602-01	Bushing Set	*	49.75
J 1610	Driver	1	14.90
J 1614	Driver	60	5.25
J 1615	Driver	*	7.50
J 1617	Assembly Tool	30	2.95
J 1619	Puller	*	21.50
J 1644	Puller	56	32.90
J 1645	Gauge	16	.50
J 1652-01	Wrench	*	4.30
J 1682-01	Tool Set	*	39.75
J 1682-13	Installing Tool	*	7.50
J 1682-14	Remover and Replacer	*	7.95
J 1686-01	Fixture	*	121.50
J 1693-02	Gauge	32	8.55
J 1698-02	Blower	*	5.65
J 1725-01	Puller	*	15.95
J 1726	Replacer	*	7.95
J 1736	Replacer	*	7.25
J 1815-5	Adjusting Tool	*	3.50
J 1820	Remover	*	18.40
J 1853	Timing Gauge	*	1.30
J 1859	Puller	62	11.25
J 1883	Gauge	16	.50
J 1895-01	Check Post	*	2.00
J 1902-01	Puller	*	19.80
J 1903	Replacer	*	7.20
J 1904-01	Screws	*	4.20
J 1906	Replacer	*	5.20
J 1907	Remover	*	4.35
J 1918-02	Remover	*	29.75
J 1927-01	Studs	*	5.20
J 1928-01	Wrench	*	6.95
J 1930	Remover	*	1.95
J 1932-01	Wrench	*	11.40
J 2029	Bender	32	7.95
J 2034	Remover	4	14.40
J 2040	Protector	30	8.55
J 2043	Spreader	67	3.95
J 2044	Spreader	67	6.95
J 2045	Gauge	30	16.75
J 2122	Cleaner	4	7.15

* Illustrated in Industrial Catalog - Form No. 58-12

↑ Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 2130	Nozzle Set	13	33.35
J 2162	Puller	66	12.50
J 2170	Installer	32	9.20
J 2173	Spacer	32	2.95
J 2174	Retainer Bracket	32	1.50
J 2175	Swaging Set	32	14.85
J 2182	Remover	32	4.25
J 2183	Rivet Set	32	7.40
J 2184	Socket Set	32	3.60
J 2187	Holder	32	4.90
J 2189	Seal Set	*	21.45
J 2190	Holder	32	21.45
J 2191	Spacer	32	1.65
J 2195	Fixture	32	3.90
J 2204	Pusher	47	10.45
J 2221-01	Driver	*	7.95
J 2222	Wrench	*	11.90
J 2223	Driver	*	8.50
J 2224	Press Plate	*	4.35
J 2225	Press Plate	*	4.35
J 2226	Driver	*	12.50
J 2227	Driver	*	9.95
J 2228	Press Plate	*	9.00
J 2229	Press Plate	*	9.00
J 2230	Driver	*	16.95
J 2231	Driver	*	7.10
J 2232	Driver	*	5.75
J 2242	Driver	49	13.75
J 2243	Driver	*	10.10
J 2244	Remover	49	10.40
J 2245	Remover	50	7.95
J 2494	Post	1	2.45
J 2496	Spacer Wrench	50	11.70
J 2497	Remover	50	14.95
J 2498	Bearing Remover	56	27.45
J 2531	Replacer	50	9.95
J 2532	Replacer	50	9.85
J 2533	Replacer	50	11.30
J 2534	Replacer	50	10.40
J 2537	Adapters	69	7.35
J 2539	Replacer	56	13.75
J 2540	Gauge	*	6.85
J 2541-02	Stand	*	22.60
J 2542	Remover and Replacer	4	2.90
J 2544	Pin	32	1.90
J 2545	Checking Gauge	32	5.75
J 2552	Remover	57	11.00
J 2554	Driver	57	7.20
J 2557	Puller	62	10.75
J 2559	Bar	30	4.80
J 2565	Puller and Driver	62	15.75
J 2573-4	Bending Iron	18	.80
J 2573-5	Gauge	16	.50
J 2573-6	Gauge	17	.50
J 2573-8	Gauge	17	.50
J 2574	Adapter	50	12.65
J 2576	Puller	47	9.45
J 2586	Fixture	33	6.60
J 2587	Guide	33	7.95
J 2590-01	Compressor	40	26.05
J 2591	Finger	40	3.85
J 2592	Stator Tool	40	1.35
J 2595	Clip	40	2.25
J 2596	Gauge	41	11.95
J 2597	Installer	47	9.85
J 2619	Hammer	80	9.95
J 2623	Collet	33	12.15
J 2624	Oil Pump Rec Set	*	28.90
J 2626	Replacer	57	11.95
J 2631	Depressor	74	2.25
J 2636	Puller	9	5.95
J 2637	Holding Tool	47	9.45
J 2644	Remover	50	2.40
J 2648	Gauge	41	1.25
J 2650	Gauge	33	4.95
J 2655	Remover	41	4.50
J 2659	Holder	47	11.70
J 2667	Press	*	23.55
J 2668	Reamer	*	13.35
J 2669	Remover	*	7.95
J 2670	Spanner	*	5.95
J 2671	Driver	13	12.50
J 2680	Staking Tool	*	7.75
J 2681	Adjusting Tool	33	21.50
J 2682	Burr Tool	75	7.45
J 2730	Inserter	4	1.55
J 2740	Wrench	*	3.15
J 2767	Inserter	76	5.95
J 2772	Inserter	74	2.25
J 2774	Service Set	10	29.05
J 2787	Puller	*	23.40
J 2788	Driver	*	4.85
J 2808	Remover and Replacer	33	18.95
J 2895	Remover	30	7.20
J 2927	Puller	62	15.10
J 2933	Holder	47	9.75
J 2934	Press Plate	23-50	6.45
J 2935	Press Plate	50	3.95
J 2936	Remover	50	5.35
J 2937	Installer	50	6.45
J 2938	Remover	50	3.95
J 2939	Installer	51	5.35
J 2940	Driver Handle	51	3.40
J 2958	Remover and Replacer	67	6.20

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 2959	Puller	13	7.15
J 2963	Remover	66	12.10
J 2980-B	Monoxivent	27-82	52.75
J 2982	Puller	62	11.50
J 2984	Puller	47	18.50
J 2985	Installer	10	3.50
J 2986-01	Remover and Installer	57	40.55
J 2995	Installer	30	9.50
J 2996	Replacer	41	3.75
J 2997	Remover and Replacer	41	5.25
J 2998	Wrench	67	4.75
J 2999	Refinisher	13	30.40
J 3042	Yoke	30	8.25
J 3044	Puller	62	9.95
J 3045	Gauge	41	11.95
J 3046	Adjuster	19	3.95
J 3048	Installer	1	8.60
J 3049	Remover	4	4.35
J 3051	Puller	*	25.85
J 3057	Reamer	*	9.75
J 3059	Reamer	4	3.05
J 3060	Reamer	4	4.60
J 3062	Remover	5	2.60
J 3063	Bearing Set	1	63.75
J 3064	Holder	5	35.00
J 3065	Gauge	33	5.75
J 3066	Installer	5	6.60
J 3067	Replacer	*	8.50
J 3069	Installer	57	8.60
J 3071-01	Reamer	*	108.75
J 3074	Tester	5	3.50
J 3078-01	Wrench	*	5.75
J 3079-02	Carb. Tool Kit	*	26.35
J 3087-01	Plate Set	*	24.50
J 3091-01	Remover	*	23.75
J 3092-01	Removing Set	*	3.40
J 3154-02	Installing Set	*	59.75
J 3171	Hook	*	6.90
J 3172	Gauge Set	*	2.00
J 3175	Remover and Replacer	41	17.95
J 3179	Lapping Set	*	58.00
J 3180	Wrench	*	1.25
J 3182	Replacer	60	4.35
J 3183	Remover	60	11.50
J 3185	Remover	30	1.75
J 3186	Puller	*	21.85
J 3189	Reamer	70	8.40
J 3197	Remover	41	11.95
J 3211	Puller	13	20.35
J 3213	Rotating Tool	5	19.95
J 3224	Guide Set	10	1.95
J 3230	Installer	51	7.50
J 3232	Adjuster	51	3.95
J 3233-01	Gauge Set	16-18	26.20
J 3234	Installer	51	5.10
J 3235	Remover	51	3.95
J 3244	Installer	51	6.80
J 3248	Installer	51	4.75
J 3249	Spacer	13	5.50
J 3250	Puller	51	14.85
J 3264	Replacer Set	47	23.25
J 3269	Checking Tool	*	24.00
J 3272-02	Piston Inserter	*	27.50
J 3274	Puller	62	12.85
J 3277-01	Installer Set	*	9.95
J 3278	Remover	*	6.00
J 3279	Replacer	*	8.90
J 3280	Replacer	*	8.90
J 3281	Puller	*	7.55
J 3282	Remover and Replacer	*	6.80
J 3283	Remover and Replacer	*	6.80
J 3284	Remover and Replacer	*	13.70
J 3285	Replacer	*	9.65
J 3287	Replacer	*	9.65
J 3289-01	Holder	51	32.25
J 3289-20	Base Only	51	8.75
J 3295	Remover	66	2.50
J 3296	Gun	76-82	3.00
J 3310	Bending Tool	33	7.95
J 3361-01	Fixture	37	87.75
J 3362	Installer	37	6.85
J 3364	Compressor	37	4.85
J 3365	Compressor	37	5.95
J 3377	Compressor	37	3.25
J 3383	Remover and Replacer	37	4.50
J 3387	Stud Set	37	4.75
J 3409	Repair Stand	*	79.90
J 3420	Remover Large	*	8.70
J 3453	Holding Bar	*	19.95
J 3455	Stud Set	1	2.95
J 3493	Puller Set	*	95.50
J 3815	Remover and Replacer	*	7.10
J 3816	Remover and Replacer	*	7.50
J 3822-02	Driver Set	*	119.30
J 3841	Arbor	*	6.95
J 3848-01	Assembly Tool	10	35.25
J 3886	Remover and Replacer	*	2.95
J 3887	Installer	*	4.60
J 3890	Installer	*	6.50
J 3891	Installer	*	6.50
J 3892	Press	*	19.95
J 3895	Arbor	*	6.95
J 3897	Installer	*	6.50
J 3899-01	Replacer	*	26.85
J 3936-01	Cleaner	10	4.00

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 3940	Cap Remover	*	9.85
J 3941	Fixture	*	19.95
J 3942	Sleeve	*	7.85
J 3955	Setting Tool	19	26.90
J 3957	Spreader	67	10.60
J 3958	Staking Tool	*	14.90
J 3959	Installer	*	8.90
J 3960	Installer	*	9.15
J 3962	Installer	*	6.50
J 4050	Spacer	51	1.75
J 4140-02	Remover	*	24.75
J 4142	Installer	*	7.25
J 4143	Installing Tool	*	4.90
J 4144	Replacer	*	4.90
J 4146	Puller	62	21.95
J 4159	Hooks	1	10.20
J 4160	Lift Plg Rem	5	3.35
J 4161	Remover and Replacer	69	39.10
J 4170	Adjusting Tool	19	3.20
J 4172	Remover and Replacer	19	10.65
J 4174	Remover	47	4.40
J 4176	Remover	1	13.20
J 4177	Replacer	1	15.50
J 4185-01	Puller	*	5.60
J 4194	Service Tool	*	19.50
J 4195	Expander	*	9.50
J 4209-01	Kit	*	196.00
J 4211	Wrench	*	2.45
J 4212	Wrench	*	3.00
J 4213	Wrench	*	3.65
J 4217-02	Jaws	*	9.85
J 4235-01	Fixture	*	24.75
J 4236-01	Assembly Tool	*	19.50
J 4237	Assembly Sleeve	*	8.90
J 4239	Expander	*	20.50
J 4240	Driver	37	6.75
J 4241	Attachment Set	*	26.50
J 4242	Fuel Wrench	*	2.80
J 4245	Pliers	80	1.95
J 4251	Spreader	67	8.60
J 4254	Remover Installer Set	*	23.60
J 4257	Studs 2	*	8.50
J 4258	Remover	48	15.95
J 4259	Installer	48	13.30
J 4260-01	Gauge	37	15.20
J 4261	Assembly Tool	37	1.50
J 4262	Sling	37	4.50
J 4263	Driver	37	19.95
J 4264	Funnel	37-80	8.50
J 4266	Assembly Hooks	1	7.35
J 4274	Assembly Tools	5	4.95
J 4275	Remover	37	8.20
J 4276	Installer	37	18.40
J 4277	Wrench	37	8.10
J 4279	Hoist	38	82.35
J 4281	Indexing Tool	38	8.75
J 4283	Fixture	43	47.50
J 4284	Studs	43	1.25
J 4285	Adjusting Tool	43	9.60
J 4286	Flange	44	25.50
J 4290	Installer	48	7.05
J 4297	Clearing Brush	*	.30
J 4298	Cleaner	*	1.60
J 4299-02	Service Kit	*	30.15
J 4310	Pilot and Cleaner	*	2.95
J 4353	Tool Set	*	21.35
J 4353-01	8124 Assembly	33	4.70
J 4354	Assembly Sleeve	*	19.80
J 4355-01	Assembly Tool	*	21.65
J 4383	Puller	10	13.50
J 4384	Wrench	*	39.50
J 4385	Wrench	*	32.65
J 4390	Remover and Replacer	30	5.15
J 4400	Puller	*	125.00
J 4414	Puller	*	94.50
J 4415	Compressor	33	12.70
J 4420	Wrench	41	3.55
J 4448	Wrench	33	1.80
J 4457	Remover	*	2.25
J 4460	Compressor	10	2.50
J 4464	Gauge	17	.50
J 4465	Gauge	16-17	.50
J 4476	Remover	1	69.50
J 4477	Removing & Replacing Set	67	25.25
J 4478		*	†
J 4484	Oil Seal Remover	57	4.95
J 4485	Oil Seal Installer	30	6.30
J 4487	Compressor	5	17.75
J 4490	Puller	66	7.50
J 4493	Bushing	62	12.95
J 4494-01	Gauge	*	39.85
J 4497-01	Remover	*	29.50
J 4498	Remover and Replacer	18	1.55
J 4511	Replacer	*	19.50
J 4512	EyeBolt	*	16.50
J 4513	Bracket	*	21.20
J 4514	Wrench	*	23.90
J 4515-01	Wrench	*	41.95
J 4516	Studs	*	5.75
J 4518	Replacer	*	19.50
J 4519	Replacer	*	19.50
J 4520	Remover	*	15.30
J 4521	Reamer	*	14.50
J 4523-01	Bearing Replacer	*	16.80

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 4524	Replacer	*	16.80
J 4525	Wrenches	*	1.90
J 4531	Yoke	30	5.75
J 4536	Lift Kit	1	46.40
J 4542	Socket	41	.80
J 4543	Wrench	38	3.25
J 4548	Remover and Replacer	48	38.95
J 4550	Pin Set Gage	o	105.60
J 4551	Installer	18	2.20
J 4552	Bending Tool	18	1.00
J 4555-02	Pinion Gauge	o	229.20
J 4556	Socket	41	.80
J 4557	Remover	*	15.30
J 4558	Remover	*	16.50
J 4565	Remover and Replacer	*	7.50
J 4566-01	Compressor and Inserter	*	32.75
J 4582	Nut Wrench	75	2.95
J 4583	Remover and Replacer	76	2.65
J 4586	Replacer	*	2.45
J 4588	Adapter	*	6.55
J 4590-03	Monox Jr	27-82	24.15
J 4599	Tool Set	38	1.25
J 4600	Hog Ring Pliers	74	5.50
J 4608	Gauge	*	6.30
J 4609	Locating Gauges	*	3.90
J 4610	Replacer	*	17.50
J 4611	Remover	*	11.95
J 4612	Reamer	*	10.50
J 4613	Remover	*	9.25
J 4614	Pliers	74	1.95
J 4626	Fixture	*	184.45
J 4627	Grinding Set	*	28.40
J 4628	Reamer	1-38	3.50
J 4637	Remover	74	5.10
J 4641	Reconditioning Set	*	208.50
J 4643	Puller	*	20.90
J 4644-1	Bushing Remover	*	3.60
J 4644-2	Installer	*	1.80
J 4644-3	Burnisher	*	19.50
J 4646	Pliers	*	3.05
J 4647	Remover	*	3.60
J 4648	Replacer	*	4.45
J 4649	Replacer	*	4.35
J 4653	Governor Wrench	30	3.25
J 4654	Installer	67	7.55
J 4655	Remover & Replacer	69	12.10
J 4656	Checking Fixture	2-38	10.25
J 4661	Wrench Set	*	10.90
J 4664	Remover	*	3.25
J 4666	Reamer Set	*	146.30
J 4667	Remover and Replacer	2	46.60
J 4668	Gauge	44	28.35
J 4670	Spring Compressor	33	13.95
J 4673	Remover and Replacer	5	11.80
J 4677	Spreader	67	7.50
J 4681	Remover	*	5.95
J 4682	Remover	*	3.85
J 4683	Bearing Replacer	*	4.40
J 4685	Bearing Remover	*	5.25
J 4687	Installer	5	5.20
J 4691	Wrench	67	2.10
J 4700	Remover and Replacer	*	22.80
J 4704	Remover and Replacer	10	35.50
J 4705	Installer	71	2.75
J 4707	Brake Adjusting Tool	71	1.50
J 4708	Gauge	30	9.95
J 4710	Alignment Set	2-41	14.95
J 4711-01	Wrench	*	8.35
J 4712	Assembly Tool	71	1.75
J 4714	Adjusting Tool	13	4.00
J 4715	Float Level Gage	17	1.40
J 4716	Gauge	16	1.40
J 4731	Aligning Gauge	33	6.95
J 4732-01	Fixture	2-33	36.90
J 4734	Insert Replacer	76	12.75
J 4735	Adjusting Tool	71	1.40
J 4740	Installing Tool	*	4.95
J 4741	Nut Wrench	*	28.35
J 4742	Remover and Installer	*	10.20
J 4743	Remover Small	*	8.25
J 4744	Remover & Installer Gear	*	11.50
J 4746	Removing Tool	*	12.75
J 4747	Selector and Driver	*	15.00
J 4749	Nut Wrench	*	5.95
J 4752	Installer	33	1.75
J 4756-03	Engine Set	*	18.10
J 4757	Attachment	80	1.20
J 4761	Puller	*	3.50
J 4768	Installer	*	7.50
J 4771	Oil Seal Driver	*	4.75
J 4773	Gauge	17	.50
J 4780	Installer	*	3.30
J 4781-02		*	†
J 4791	Remover	*	11.50
J 4794-01	Puller	*	7.85
J 4799	Brake Bleeder	*	50.00
J 4822	Reamer	5	4.60
J 4824-01	Remover	*	23.75
J 4830-01	Seal Remover	44	12.15
J 4832	Tool Set	2-34	43.25
J 4850	Remover and Installer	*	15.30
J 4852	Sleeve Puller	*	12.50
J 4853	Installer	*	14.50

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 4863	Yoke Rep Set	*	36.50
J 4866-01	Gauge	19-21-82	67.70
J 4869	Remover and Replacer	*	15.15
J 4870	Puller	*	11.25
J 4871	Large Puller	*	16.35
J 4872-01	Test Panel	38	36.50
J 4880	KMO 634 Pliers	80	1.80
J 4889	Reconditioning Set	*	24.75
J 4894-01	Inserter	*	22.10
J 4895-01	Retainer	*	1.25
J 4897-02	Gauge	*	39.85
J 4898	Installer and Remover	*	20.80
J 4920	Torque Tool	38	10.75
J 4969	Timing Gauge	*	.90
J 4970-01	Reamer	*	107.75
J 4971	Reamer Set	*	117.15
J 4972	Installer and Remover	*	14.95
J 4973	Injector Holder	*	9.85
J 4974-01	Injector Set	*	27.35
J 4974-1	Cleaner	*	1.80
J 4974-3	Remover	*	1.70
J 4974-4	Cleaner	*	2.20
J 4974-6	Reamer	*	14.50
J 4974-9	Cleaner	*	2.80
J 4976	Fixture	*	5.85
J 4982	Socket Wrench	*	7.95
J 4983-01	Wrench	*	2.80
J 4984	Socket Wrench	*	13.90
J 4985	Reamer	*	15.95
J 4986-01	Seat Reamer	*	14.75
J 4991-16	Gauge	*	3.00
J 4996	Remover	*	29.75
J 5066-GA	Monoxivent	27-83	54.70
J 5071	Gauge	34	1.50
J 5092	Plunger Remover	5	6.20
J 5094	Lifter Remover	5	12.95
J 5097	Unloading Tool	5	4.60
J 5099	Cleaning Brush	5	.45
J 5119	Gauge	*	55.75
J 5120	Gauge	16	1.90
J 5124	Remover and Replacer	*	15.95
J 5127-01	Gauge Set	16-18	11.15
J 5127-2	Gauge	17	.50
J 5128	Flywheel Tool Set	2-34	7.35
J 5131-2	Bushing	*	10.50
J 5133	Compressor	38	4.85
J 5137	Compressor	6	8.40
J 5139	Remover	34	.55
J 5152	Installer and Remover	*	49.75
J 5153	Installer and Remover	*	49.75
J 5154	Installer	34-38	8.20

Tool No.	Description	Page No.	Suggested Dealer Price
J 5157	Assembly Clamp	34	1.75
J 5158-02	Remover & Replacing Set.	6	6.35
J 5158-4	Adapter	*	.75
J 5159	Shaft Bearing Prot	60	2.80
J 5171	Compressor	6	40.45
J 5172	Pliers	80	5.50
J 5174	Starter Switch	19	3.95
J 5175	Bearing Assembly Tool	14	4.50
J 5176	Testing Gauge	63	26.25
J 5177	Remover	34	7.65
J 5178	Scale	80	7.15
J 5182	Collar	63	3.30
J 5184	Checking Scale	19	7.15
J 5186	Piston Ring Comp.	63	2.60
J 5188	Installer	63	4.95
J 5189	Installer	63	4.95
J 5190	Bearing Remover	60	9.75
J 5191	Bearing Installer	63	4.75
J 5193	Rod Inserter	63	2.80
J 5195	Gauge	16	1.65
J 5196	Gauge	16	1.80
J 5197	Bending Tool	18	1.90
J 5198	Gauge	17	.85
J 5202	Monoxivent	83	27.10
J 5205	Fixture	63	5.25
J 5206	Adaptor Studs	63	3.60
J 5207	Remover and Replacer	80	2.50
J 5209	Installer	*	4.75
J 5210	Inserter	63	4.05
J 5214	Adapter	38	25.50
J 5218	Gauge	17	.85
J 5219	Wedge Driver	18	.85
J 5223-01	Gauge	51	43.95
J 5224	Compressor	69	19.50
J 5227	Gauge	17	.50
J 5228	Gauge	17	.50
J 5231	Spreader	57	25.30
J 5232	Tool	18	1.05
J 5236	Bearing Remover	62	16.95
J 5237	Tester	*	70.80
J 5238	Disassembly Tool	6	3.95
J 5239	Rod Set	10	2.20
J 5240	Installer	6	6.60
J 5250	Installer Set	2	8.95
J 5251	Holding Fixture	6	49.45
J 5254	Installer	60-63	5.50
J 5255	Installer	63	5.95
J 5256	Stainless Steel Hose	*	68.75
J 5259	Wrench	60	3.00
J 5260	Bending Tool	34	7.30
J 5261	Adapter	*	27.00
J 5268	Valve Lifter	6	1.95

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 5283	Valve Spline Aligner	63	2.75
J 5284	Pliers	14	2.45
J 5286	Injector Tube Set	*	113.90
J 5288	Blower Assembly	83	35.45
J 5290	Puller	62	9.75
J 5292	Replacer	51	6.80
J 5293	Holding Tool	48	9.00
J 5294	Adapter	48	5.45
J 5297-01	Eye Tester	83-86	60.40
J 5324	Spreader	67	8.95
J 5338	Dynaflow Installer	41	4.40
J 5339	Dial Plug Extension	80	1.50
J 5341	Tool Set	*	108.25
J 5343	Wrench	67	4.50
J 5345-01	Kit	*	26.00
J 5347	Gauge	*	192.70
J 5355	Adapter	*	4.95
J 5356	Remover	*	34.55
J 5359	Remover	*	10.90
J 5362	Installer	14	5.50
J 5363	Wrench	79	4.50
J 5364	Installer	52	5.70
J 5365	Remover	52	10.95
J 5366	Installer	52	11.70
J 5367	Installer	52	5.70
J 5368	Remover	57	3.85
J 5369	Installer	57	5.15
J 5370	Installer	57	2.40
J 5372	Spreader	52	21.00
J 5373		*	†
J 5374	Gauge	6	20.90
J 5381	Remover	38	15.10
J 5382	Replacer	38	5.05
J 5384	Conv Hold Tool	38	1.50
J 5385	Gauge	38	.75
J 5386	Driver	39	6.85
J 5388	Converter	39	6.85
J 5389	Assembly Tool	39	1.25
J 5390	Installer	39	6.65
J 5395	Installer	52	9.05
J 5397	Remover and Replacer	74	6.25
J 5398	Adjuster	64	3.25
J 5399-A	Gauge	17	.95
J 5403	Pliers	39-80	1.80
J 5404	Guide Pin	72	1.85
J 5405-01	Installing Tool	72	3.35
J 5406	Assembly Ring	72	1.95
J 5407	Gauge	*	3.10
J 5408	Remover and Replacer	60	5.05
J 5409	Remover	60	.95
J 5413	Wrench	44	3.15
J 5418	Charging Lines	77	1.75 ea.
J 5420	Gauge Adapter	77	1.15
J 5421	Thermometer	77	1.75
J 5424	Tube Wrench Set	77	4.15
J 5424-2	Tube Wrench	77	2.35
J 5425	Seal Centering Tool	77	4.75
J 5426	Valve Key	77	.80
J 5427	Valve Key	77	.80
J 5428-01	Pump	77	54.50
J 5428-11	Refrig. Oil	77	.55
J 5429	Gauge	17	.95
J 5430	Wrench	75	2.95
J 5433-01	Stand	72	13.95
J 5437	Cleaner	*	4.30
J 5438	Feeler Gauge	*	10.95
J 5439-02	Gauge Set	*	291.90
J 5440	Driver	64	4.65
J 5441	Installer	44	2.30
J 5448-03	Carb. Tool Kit	*	16.30
J 5449	Wrench	75	5.05
J 5453	Goggles	77	1.75
J 5454	Wrench	77	3.30
J 5457	Gauge	17	.50
J 5458	Float Gauge	17	.50
J 5462	Gauge Hook Up	77	19.75
J 5465	Gauge	17	.95
J 5468-01	Set	*	135.00
J 5470	Belt Tightener	64	4.45
J 5472	Removing & Replacing Set	67	29.50
J 5473-01	Puller	62	12.60
J 5474	Wrench	19	6.05
J 5475	Float Level Gauge	17	.50
J 5476	Retaining Ring Installer	18	1.95
J 5478	Assembly Fixture	44	3.70
J 5481	Test Rod	44	2.25
J 5482	Wrench	44	2.95
J 5484	Holding Fixture	44	7.45
J 5492	Checking Fixture	*	10.75
J 5494	Valve Spring Remover	6	19.55
J 5496	Bending Tool	18	.70
J 5500	Wrench	74	3.30
J 5501	Wrench	19	2.60
J 5502	Remover and Replacer	52	39.50
J 5503	Remover	64	7.65
J 5504	Puller	66	12.60
J 5506	Installer	52	5.05
J 5507	Installer	52	4.30
J 5508	Bearing Cone Remover	52	4.95
J 5510	Gauge	17	.50
J 5511	Trim Molding Installer	76	3.95
J 5512	Socket	48	3.75
J 5513	Piston Scale	10	13.95
J 5514	Yoke Remover	48	10.45

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 5515	Feeler and Scaler	10	13.95
J 5517	Installer Tool	64	3.95
J 5518	Clamp Set	*	17.50
J 5521	Remover	52	4.55
J 5526	Jack Pad	39	17.25
J 5527	Remover and Replacer	*	4.60
J 5528	Remover and Replacer	*	5.55
J 5529	Remover and Replacer	*	7.85
J 5536	Remover and Replacer	69	3.95
J 5537	Remover and Replacer	74	7.05
J 5538-01	Assembly Tool	10-23	43.10
J 5538-9	Adapter Kit	o	6.15
J 5539	Studs	*	4.30
J 5540	Feeler and Scaler	10	7.65
J 5544	Remover and Replacer	74	6.80
J 5547	Torque Socket	2	3.25
J 5550	Remover	52	5.25
J 5552	Gauge	17	.50
J 5553	Gauge	17	.50
J 5562	Remover and Replacer	64	3.25
J 5563	Adjusting Tool	64	1.50
J 5564	Remover and Replacer	6	4.30
J 5566-03	Pitman Arm Remover	66	9.15
J 5567	Adjusting Gauge	30	8.55
J 5569	Compressor	10	4.25
J 5571	Hook	67	3.50
J 5573	Bearing Installer	64	2.95
J 5574	Tension Tool	64	3.75
J 5579	Gauge Set	*	292.25
J 5580	Gauge	*	292.25
J 5581	Gauge Set	*	321.85
J 5583	Adapter	80	1.65
J 5584	Piston Ring Compressor	10	3.50
J 5585	Cleaner	*	4.30
J 5586	Pliers	81	5.70
J 5588	Gauge	39	4.80
J 5589	Assembly Tool	*	2.50
J 5590	Installer	14-30	7.15
J 5591	Adapter Plate	83	16.25
J 5598	Replacer	6	5.45
J 5599	Replacer	6	5.45
J 5601	Piston Installer	11	4.25
J 5605	Fixture	34	3.90
J 5606	Ring Tool	*	2.25
J 5608	Compressor	*	2.50
J 5609	Gauge	*	3.95
J 5610	Wrench	75	5.50
J 5611	Installer	*	7.50
J 5619	Installer	64	3.75
J 5623	Reamer	*	6.10
J 5625-01	Installer	*	3.25
J 5626-01	Installer	*	3.25
J 5627	Nut Wrench	*	74.50
J 5629	Linkage Gauge	*	6.55
J 5630	Installing Tool	72	2.95
J 5631-01	Gauge	*	33.50
J 5633	Wrench	*	4.25
J 5640	Gauge	16	.80
J 5641	Plug Set	18	.90
J 5647	Setting Gauge	52	80.50
J 5648	Wrench	60	1.25
J 5650	Assembly Tool	72	1.80
J 5651	Gauge	17	.50
J 5652	Gauge	16	.50
J 5655	Conversion Set	*	6.30
J 5656	Compressor	6	15.95
J 5659	Wrench	76	4.25
J 5660	Wrie Gauge	16	.80
J 5661	Extractor	18	1.20
J 5664	Puller	60	12.80
J 5667	Nut Wrench	*	19.00
J 5669	Installer	*	9.15
J 5670	Wrench	*	14.80
J 5672	Installer	*	14.75
J 5673	Nut Wrench	*	23.25
J 5676	Installer	*	6.45
J 5677	Installer	*	7.50
J 5678	Remover	52	4.95
J 5679	Remover	52	5.20
J 5680	Wrench	64	3.20
J 5681	Remover Plates	*	5.90
J 5682	Clamp Set	*	17.25
J 5683	Gauge	17	.70
J 5684	Installing Tool	11	4.25
J 5690	Remover	53	5.70
J 5691	Remover	53	5.35
J 5692	Puller Adapter	*	2.75
J 5697	Staking Tool	*	12.95
J 5698	Driver	*	7.25
J 5709	Support Stand	2	5.20
J 5710	Gauge	6	4.10
J 5712	Holder and Compressor	6	24.65
J 5713	Reamer	7	8.25
J 5715	Reamer	7	3.50
J 5716	Stud Installer	7	4.25
J 5721	Tube Nut Wrench	78	9.40
J 5722	Plug and Head Set	78	4.60
J 5725-01	Gauge	78	9.50
J 5727	Wrench	19	2.85
J 5734	Valve Guide Installer	7	5.45
J 5736	Installer	11	3.80
J 5738	Drill	79	5.40
J 5740-01	Remover	53	5.50
J 5741	Bearing Remover	57	33.75

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 5742-01	Aligning Blocks	76	1.50
J 5746	Bearing Installer	57	7.80
J 5747	Seal Installer	57	2.95
J 5748	Remover	22-57	6.50
J 5749	Installer	48	2.55
J 5750	Holding Stand	*	22.15
J 5751	Seal Installer	7	3.95
J 5752	Gauge	7	.75
J 5753	Remover and Replacer	11-23	17.30
J 5754	Remover	61	15.65
J 5755	Installer	61	8.60
J 5757	Inserter	*	2.45
J 5763	Box	7	4.50
J 5764	Injector Tester	*	141.00
J 5768	Replacer	23-53	5.70
J 5769	Studs	*	3.80
J 5771	Studs	*	3.70
J 5773	Gauge Set	16-18	3.25
J 5775	Gauge	14	3.50
J 5777	Assembly Tool	31	1.65
J 5778	Remover and Replacer	31	5.95
J 5780	Installing Tool	48	9.10
J 5781	Fixture	*	42.30
J 5787	Seal Protector	61	5.50
J 5788	Installer	2	8.80
J 5790	Lifter Tester	7	54.50
J 5793	Monoxivent	27	93.25
J 5794	Wrench	72	3.25
J 5798	Reamer	70	7.05
J 5799	Spreader	68	9.40
J 5801	Stud Installer	7	2.50
J 5802	Stud Remover	7	1.25
J 5804	Gauge	41	3.15
J 5805	Depth Gauge	72	4.50
J 5806	Installer	41	4.20
J 5808	Extension Rod	42	2.85
J 5810	Adapter	81	1.75
J 5813	Installer	61	3.75
J 5814-01	Remover and Replacer	39	33.40
J 5814-15	Plate	39	5.50
J 5816	Bushing Replacer	42	4.75
J 5818	Seal Installer	57	11.70
J 5819	Gauge	31	4.40
J 5821	Cleaning Tank	7	21.25
J 5822	Remover	61	13.50
J 5824	Aligning Tool	31	11.75
J 5825	Puller	11	8.95
J 5826	Screw Driver	42	1.25
J 5830	Reamer Set	7	14.30
J 5830-1	Reamer	7	4.60
J 5831	Adapter Plate V	83	28.85
J 5839	Tool Set	*	39.25
J 5840	Fixture	*	27.50

Tool No.	Description	Page No.	Suggested Dealer Price
J 5853	Torque Wrench	81	17.95
J 5855	Remover and Installer	19	5.95
J 5856	Engine Stand	28-83	80.00
J 5859	Seal Remover	31	12.70
J 5860	Adapter	2	2.50
J 5862	Monoxivent	27-83	42.90
J 5864	Support Rod	44	1.75
J 5867	Adjusting Tool	44	3.75
J 5870	Adjusting Tool	44	3.95
J 5875	Spring Compressor	44	7.35
J 5878	Clutch Assembly Fixture	44	3.30
J 5879-01	Gauge Pin	44	.50
J 5880-01	Adjusting Wrench	45	24.50
J 5883	Adjusting Tool	45	32.95
J 5884	Assembly	45	3.90
J 5886	Compressor	45	12.50
J 5887	Bending Tool	45	2.95
J 5888	Removing & Replacing Set	68	18.30
J 5891	Adapter Plate	83	15.15
J 5892-1	Compressor	7	3.95
J 5893	Wrench	76	3.75
J 5895	Nut Wrench	*	6.55
J 5896	Mainshaft End Tool	*	3.25
J 5897	Nut Wrench	76	5.95
J 5899-01	Gauge	42	25.95
J 5900	Adapter	64	.95
J 5901	Puller Set	*	26.40
J 5901-1	Hammer and Shaft	*	7.50
J 5901-2	Adapter	*	14.80
J 5901-3	Remover Adapter	*	2.70
J 5902	Liner Hone	2	78.95
J 5904	Adapter	*	20.65
J 5905	Spacer	53	3.85
J 5906	Gauge	39	5.30
J 5907	Pressure Gauge	81	11.50
J 5908	Gauge	16	1.10
J 5910	Lifting Hooks	2	7.35
J 5913	Bushing Installer	42	5.95
J 5915	Carburetor Tool	17	.55
J 5916	Gauge	17	.55
J 5917	Gauge	17	.55
J 5918	Gauge	16	.55
J 5920	Gauge	16	.55
J 5921	Gauge	16	.50
J 5922	Installer	78	3.90
J 5923-01	Fixture	14	8.75
J 5930	Driver	34	4.50
J 5942	Support	45	8.90
J 5943	Compressor	45	6.65
J 5946	Puller	34	14.95
J 5948	Driver	34	7.10
J 5952	Inserter	11	4.25

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 5954	Loader	69	86.50
J 5955	Wrench	*	14.80
J 5956	Primer	*	9.75
J 5959	Indicator and Attacher	*	34.50
J 5961	Compressor	7	5.55
J 5962	Remover	8	.50
J 5973	Spacer	53	12.05
J 5975	Pressure Sets	45	42.50
J 5976	Wrench	45	1.95
J 5977	Remover and Replacer	45	18.50
J 5978	Checking Tool	8	8.25
J 5979	Driver Set	21-81	27.95
J 5979-1	Driver	21	7.35
J 5979-2	Driver	21	5.50
J 5979-3	Driver	21	3.50
J 5979-4	Driver	21	3.50
J 5979-5	Driver	21	5.05
J 5979-6	Driver	21	4.55
J 5981	Remover	74	2.50
J 5983	Installer	2	5.40
J 5984	Clip Former	76	5.95
J 5986	Wrench	76	1.95
J 5988	Fixture	8	24.65
J 5990	Installer	*	3.95
J 6036	Reamer	8	3.50
J 6039	Gauge	17	.50
J 6040-01	Gauge Set	16-18	1.00
J 6042	Reamer Set	8	17.00
J 6043-1	Adapter Set	*	10.40
J 6045	Centering Tool	69	9.95
J 6046	Remover	69	14.95
J 6047-01	Pin Remover & Replacer	11-23	38.70
J 6049-01	Valve Set	*	29.75
J 6056	Wire Gauge	16	1.70
J 6057	Wire Gauge	16	1.70
J 6058	Bending Tool	18	1.35
J 6061	Wire Gauge	16	1.70
J 6063	Gauge	*	3.85
J 6065	Holding Tool	69	13.75
J 6066	Compressor	8	6.05
J 6068	Gauge	45	7.85
J 6069	Installer	45	3.85
J 6076	Humidicator	78	9.60
J 6078	Installer	*	7.05
J 6079	Remover	*	4.35
J 6080	Installer	*	7.45
J 6081	Installer	o	9.50
J 6083	Ring Pliers	81	1.95
J 6084	Leak Detector	78	9.45
J 6086	Installer	78	4.40
J 6090	Installer	*	9.95
J 6091	Remover	*	7.70
J 6092	Alignment Blocks	*	2.75

Tool No.	Description	Page No.	Suggested Dealer Price
J 6094-01	Gauge Set	16-18	3.95
J 6095-01	Adjusting Set	24	99.25
J 6098	Remover and Replacer	2	17.95
J 6100	Remover	11	8.05
J 6104-01	Wrench	*	19.75
J 6105	Valve Key Set	78	5.40
J 6107	Installer	*	6.95
J 6108	Torsion Set	69	111.40
J 6110	Installer	*	9.55
J 6111-01	Checking Gauge	*	2.95
J 6112	Installer	*	6.95
J 6114	Adapter Plate	3-28-83	49.75
J 6115-01	Fixture	34	35.95
J 6116-01	Fixture	34	8.40
J 6118	Seal Installer	34	8.50
J 6119	Protector	35	2.25
J 6120-01	Retainer	35	.50
J 6121	Cover Remover	35	16.95
J 6122-01	Retainer	35	.90
J 6123	Gear Remover	35	14.95
J 6124	Remover and Replacer	35	7.95
J 6125	Hammer Assembly	35	9.90
J 6126	Fixture	35	1.95
J 6127	Gauge	35	8.50
J 6129	Compressor	35	3.90
J 6133	Bearing Driver	35	5.90
J 6134	Locating Gauge	35	1.25
J 6135	Clutch Retainer	35	4.45
J 6136	Remover	35	14.95
J 6154	Ring Gear	*	2.35
J 6161	Pressure Hose	*	3.50
J 6163	Adapter	78	2.75
J 6166	Adjuster	71	1.65
J 6171	Remover	*	4.35
J 6178	Remover and Replacer	3	34.95
J 6175	Installer	*	8.90
J 6176	Puller	22-58	6.50
J 6177	Fixture	53	32.25
J 6178	Wire Gauge	16	1.70
J 6179	Gauge	17	.95
J 6180	12 Ton Ram	*	59.95
J 6180-01	12 Ton Ram	83	59.95
J 6185	Spreader	53	32.85
J 6187	Puller Adapter	*	2.40
J 6188	Lever Gauge	*	10.50
J 6189-01	Gauge Set	16-18	5.00
J 6191-01	Remover	58	12.35
J 6192	Wrench	53	11.55
J 6194-01	Bearing Support	53	20.85
J 6197	Installer	53	5.35
J 6198	Remover	53	4.25
J 6199-01	Puller	53	23.95
J 6200	Installer	53	6.80
J 6203	Remover Plate	*	4.35

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 6204	Spring Compressor	8	9.40
J 6207	Pump Assembly	83	34.60
J 6208	Adapter Kit	*	5.95
J 6212	Tension Tool	78	3.25
J 6213	Seal Guide	58	3.25
J 6215	Pinion Press	23-48	34.75
J 6216	Compressor	64	5.60
J 6217	Installer	64	1.45
J 6219	Seal Installer	64	4.10
J 6220	Remover and Replacer	65	6.35
J 6221	Remover and Replacer	65	3.00
J 6222	Seal Protector	65	4.05
J 6223	Adapter	65	1.95
J 6224	Adapter	65	2.50
J 6245	Holding Tool	54	3.95
J 6246	Handle	54	9.80
J 6247	Swing	54	4.50
J 6248	Installer	42	4.50
J 6251	Guide Studs	54	1.50
J 6255	Installer	54	8.60
J 6257	Bearing and Retainer	22-58	3.60
J 6258	Adapter	22-81	3.45
J 6259	Music Wire	*	.50
J 6260	Music Wire	*	.50
J 6261	Music Wire	*	.50
J 6263	Installer	54	9.20
J 6265	Remover	18	1.20
J 6266-01	Gauge	54	41.00
J 6266-16	Kit	*	6.75
J 6267-01	Gauge Set	16-18	14.80
J 6268	Gauge Set	16-18	8.25
J 6270	Blower Service Set	*	93.95
J 6271	Fits All Valve	78	1.75
J 6272	Multi Opener	78	12.50
J 6273	Reamer	*	13.20
J 6275	Adapter Screws	*	5.80
J 6276	Adapter Screws	*	5.25
J 6277	Reamer	*	13.20
J 6278	Remover and Installer	65	7.05
J 6279	Remover	65	2.50
J 6280	Installer	65	2.50
J 6281	Adapter	65	3.15
J 6282	Gauge	35	9.65
J 6284	Reamer	*	9.80
J 6285	Staking Tool	65	3.65
J 6289	Holder	48	7.95
J 6292	Remover	61	10.65
J 6293	Holding Tool	65	4.55
J 6295-01	Flange Remover	48	10.45
J 6296-01	Adjusting Tool	*	6.95
J 6297	Remover	*	3.95
J 6298	Beam Reamer	*	8.60
J 6299	Beam Reamer	*	10.85
J 6300	Beam Reamer	*	10.85

Tool No.	Description	Page No.	Suggested Dealer Price
J 6301	Stud Installer	8	5.30
J 6303	Remover and Replacer	*	7.45
J 6304	Remover and Replacer	*	7.95
J 6305	Guide Set	*	1.95
J 6305-01	Guide Set	11	1.95
J 6306	Remover	*	7.85
J 6307	Aligning Arbor	*	7.95
J 6308	Timing Gauge	*	3.35
J 6309	Timing Gauge	*	3.35
J 6310	Aligning Housing	45	11.50
J 6311	Monoxivent	27	109.50
J 6314	Installer	45	7.15
J 6318	Compressor	69	13.25
J 6320	Protector	78	2.80
J 6322	Plate Puller	78	7.25
J 6323	Plate and Installer	78	9.60
J 6324	Gauge	8	4.50
J 6325	Remover and Replacer	74	3.75
J 6326	Gauge	17	.50
J 6327	Remover and Replacer	70	7.40
J 6328	Reamer	70	9.85
J 6329-01	Arbor	*	8.55
J 6330	Reamer	70	7.05
J 6331	Driver	*	7.40
J 6332	Remover & Installer Set	*	19.90
J 6334	Installer Set	*	47.35
J 6335	Remover	74	1.75
J 6336	Pump Gauge	16	.50
J 6337	Gauge	17	.60
J 6338	Gauge	16	.50
J 6341	Reamer	8	8.00
J 6342-01	Check Clamp	36	.95
J 6343	Gauge	36	5.10
J 6344	Gauge	36	4.80
J 6345	Engine Repair Stand	3-28-83	281.00
J 6347	Engine Stand Adapter	*	56.75
J 6348	Protector	65	5.95
J 6349	Installer	3	8.00
J 6351	Pulley Puller	79	12.50
J 6354	Adjuster	61	1.35
J 6355	Checking Gauge	*	7.50
J 6356	Remover and Replacer	3	46.60
J 6357	Checking Gauge	*	7.50
J 6360	Remover and Replacer	11	12.50
J 6362	Reamer Set	*	145.35
J 6366-01	Tool Set	*	28.35
J 6367	Remover	54	13.55
J 6368	Installer	54	4.25
J 6369	Remover and Replacer	54	16.70
J 6371	Holder	48	7.95
J 6373-01	Bending Tool	36	7.95
J 6377	Replacer	23-54	3.95

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 6378	Remover	58	13.65
J 6379	Retainer Ring	58	3.15
J 6380	Installer	54	4.35
J 6381-02	Gauge	54	49.50
J 6382	Remover	*	7.30
J 6384	Spring Compressor	8	9.90
J 6385	Remover	*	8.10
J 6386	Position Tool	58	13.65
J 6387	Parts Rack	*	325.00
J 6388	Adapter Plate	*	35.00
J 6389	Valve Tool	79	2.75
J 6390	Grinder Set	*	18.00
J 6392	Remover	8	6.70
J 6395	Plate Holder	81	7.35
J 6399	Remover and Installer	31	5.50
J 6402	Protector	79	2.75
J 6403-01	Bearing Installer	45	10.35
J 6405	Holder and Remover	69	22.50
J 6407	Holder	81	19.35
J 6413	Timing Gauge	*	3.35
J 6414	Timing Gauge	*	3.75
J 6416	Installer	*	7.15
J 6417		*	†
J 6418	Press Plate	81	8.35
J 6419-01	Bearing Driver Set	*	44.60
J 6421	Bearing Remover	*	16.95
J 6424	Gauge	63	6.25
J 6429-01	Timing Gauge	*	3.75
J 6430	Lifting Eye	*	1.65
J 6432-01	Retainer	*	1.95
J 6435	Pliers	81	2.50
J 6436	Connector Set	*	16.35
J 6438	Spring Compressor	*	8.35
J 6440	Bearing Installer	45	10.35
J 6441	Disc Set	o	283.40
J 6443	Adapter	*	21.45
J 6444	Remover and Replacer	*	1.65
J 6445-28	Nozzle Tester	*	92.50
J 6445-37	Nozzle Tester	*	18.95
J 6445-38	Nozzle Fixture	*	9.20
J 6445-50	Nozzle Tester	*	1.40
J 6446	Remover	66	8.15
J 6448-01	Fixture	65	12.50
J 6455	Remover	46	12.15
J 6456	Depth Gauge	31	.85
J 6457	Adjusting Tool	*	6.95
J 6458	Wrench	*	19.30
J 6459	KMO 652 Wrench	*	17.95
J 6463	Bearing Remover	*	1.95
J 6464	Bearing Installer Set	*	6.65
J 6466	FD Manuals	o	1.00
J 6467	Checking Fixture	*	41.80
J 6468	Tool Set	24	151.25
J 6469	Adjusting Tool Set	46	149.75
J 6471-02	Adapter	*	31.35
J 6474	Remover & Installer Set	*	10.95
J 6481	Wrench	76	5.50
J 6482-01	Conversion Kit	54	20.50
J 6486	Switch and Wrench	76	5.45
J 6492	Gauge	16	1.40
J 6495	Float Gauge	*	.30
J 6496	Plug Socket	*	1.15
J 6498	Wrench Extension	36	2.85
J 6499	Adapter Set	46	42.50
J 6502	Aligner	*	16.55
J 6504	Remover Screw	36-48	2.30
J 6505	Installer	36-49	7.25
J 6506	Removing & Installing Tool	74	6.25
J 6507	Installer	3	7.75
J 6508	Gauge	14	4.15
J 6509	Pilot Tool	69	9.65
J 6511	Gauge	54	8.65
J 6513	Seal Installer	14	3.40
J 6514	Aligning Gauge	49	18.35
J 6521-01	Carb Tool Kit	16-18	6.15
J 6523	Installer	*	9.80
J 6525	Bearing Remover	22-58	24.35
J 6526-01	Adapter Plate	*	35.00
J 6527	Adapter Plate	*	35.00
J 6528	Installer	3	6.50
J 6529-02	Disc Set	*	32.35
J 6530-01	Bearing Remover	*	51.85
J 6531	Remover	23-55	22.80
J 6533	Remover	55	5.75
J 6534	Wrench	*	39.50
J 6535	Spacer Block	8	5.45
J 6539	Installer	65	6.60
J 6541	Installer	70	7.15
J 6544	Holding Tool	49	7.75
J 6546-01	Test Kit	*	54.90
J 6547	Installer	23-55	5.15
J 6552-01	Remover	23-55	23.15
J 6553-01	Remover	23-55	17.40
J 6555	Remover	23-55	22.40
J 6556	Bending Tool	18	1.10
J 6557	Gauge	39	14.40
J 6560	Assembly Sleeve	39	7.30
J 6561	Installer	39	16.00
J 6567	Remover	*	23.75
J 6568	Installer	*	7.25
J 6569	Remover	*	2.95
J 6570	Installer	*	4.90
J 6571	Holding Fixture	55	30.05
J 6573	Gauge	36	1.65

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 6580	Assembly Tool	39	17.65
J 6581	Remover and Installer	39	9.25
J 6582	Installer	39	6.10
J 6583	Installer	40	5.70
J 6584	Seal Installer	40	8.35
J 6585	Assembly Remover	40	5.90
J 6586	Remover	42	3.35
J 6590	Spreader	68	15.35
J 6591	Spreader	68	16.95
J 6592-01	Wrench	76	7.15
J 6593	Remover	66	10.65
J 6596	Puller	*	12.60
J 6599	Compressor	*	9.95
J 6600	Gauge Adapter	*	23.90
J 6601	Gauge Adapter	*	23.90
J 6608	Remover and Installer	74	3.25
J 6609	Wrench	74	1.40
J 6618	Nut Wrench	72	8.75
J 6619	Remover and Installer	61	5.75
J 6621	Reamer	8	4.60
J 6624	Wrench	75	4.40
J 6626	Alignment Blocks	77	1.90
J 6627	Ball Joint Remover	66	14.75
J 6628	Gauge	17	1.00
J 6632	Pitman Arm Remover	66	16.10
J 6638	Holding Fixture	40	19.40
J 6640	Detector	83-86	24.35
J 6643	Installer	40	6.80
J 6645	Reamer	*	14.50
J 6646	Gauge	17	.75
J 6647	Ring Compressor	11	3.00
J 6648	Remover	*	5.95
J 6649	Nut Wrench	o	10.10
J 6650	Gauge Set	*	8.95
J 6650-11	Gauge	*	1.25
J 6650-12	Gauge	*	1.25
J 6650-13	Gauge	*	1.25
J 6653	Gauge	*	1.55
J 6655	Wrench Extension	46	3.60
J 6657	Remover and Installer	61	6.50
J 6659	Holding Bracket	19	6.50
J 6660	Tachometer	19-83-86	39.75
J 6661	Installer	22-58	8.60
J 6663	Aimer	84	29.80
J 6665	Motor Oil Dye	84	6.50
J 6670	Broach Set	*	38.50
J 6671	Installation Set	*	16.60
J 6672	Assembly and Adapter	*	6.70
J 6673	Shaft Pilot	*	7.30
J 6674	Seal Reamer	*	13.95
J 6675	Seal Reamer	*	12.90
J 6676	Puller	*	16.15
J 6678	Spacer	*	2.50
J 6684	Holding Bracket	14	1.75
J 6685	Button Lg	14	2.95
J 6686	Button Sm	14	2.45
J 6687	Plug	15	4.30
J 6688	Installer	15	10.50
J 6692	Gauge Hose Assembly	*	17.95
J 6694	Gauge Adapter	*	23.90
J 6695	Gauge	36	3.50
J 6700	Driver	*	.35
J 6701	Tire Tool	*	192.25
J 6702	Protector	*	36.80
J 6704	Jack	*	82.50
J 6705-01	Wrench	*	8.35
J 6706	Wrench	*	15.95
J 6707	Jack	*	333.00
J 6708	Protector	*	18.85
J 6709-01	Pry Bar	*	13.15
J 6710	Remover	*	3.60
J 6711	Handle	*	13.85
J 6712	Aligning Bar	*	3.50
J 6713	Pry Bar	*	3.95
J 6714	Charging Assembly	*	43.65
J 6715	Tire Tool	*	192.25
J 6716	5 Ton Jack	*	56.25
J 6717	Adapter	*	13.45
J 6722	Wrench	*	7.90
J 6723	Nut Wrench	*	10.90
J 6732	Remover & Installer	o	7.30
J 6733	Tensioning Tool	19-65	15.55
J 6734	Tool Kit	*	65.15
J 6737	Chuck Assembly	*	24.60
J 6741	Axle Jack	58	45.50
J 6742	Thermometer	79	8.50
J 6749	Nut Wrench	*	2.50
J 6750	Removing Set	*	30.65
J 6751	Removing Set	*	20.75
J 6752	Installation Set	*	19.65
J 6753	Broach Set	*	47.95
J 6754	Seal Reamer	*	24.50
J 6755	Seal Reamer	*	17.95
J 6756	Pilot	*	9.95
J 6757	Spacer Nut	*	5.70
J 6758	Adapter	*	13.50
J 6761-01	Adapter	*	24.95
J 6762-01	Gauge	*	40.90
J 6765	Nut Wrench	*	3.75
J 6766	Power Equipment Set	84	15.10
J 6767	Adapter	*	15.65
J 6769	Adapter	22	3.45
J 6770	Tool Set	*	84.00
J 6771	Wrench	68	10.85

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 6772	Injector Cut Out Tool	*	5.35
J 6773	Installer	70	5.35
J 6776	Adapter Ring	36	4.10
J 6777	Adapter	84	5.60
J 6778	Adapter	84	5.70
J 6779	Adapter	84	5.95
J 6780	3 In Y Connector	84	3.50
J 6781	Flex Tubing	84	15.85
J 6782	Setting Gauge	55	25.60
J 6783	Installer Plate	22-58	4.80
J 6786	Remover and Installer	*	61.60
J 6788-01	Wrench	81	9.50
J 6791	Installer	*	3.50
J 6793	Seal Remover	40	11.65
J 6795	Cover and Remover	*	4.10
J 6798	Crushproof Hose	84	12.95
J 6801	Adapters	84	5.25
J 6831	Adapters	84	6.95
J 6833	Liner Remover	*	27.65
J 6834	Float Gauge	17	.50
J 6836	Adapter Kit	58	31.85
J 6837	Overhaul Stand	*	420.00
J 6838	Wire Gauge	16	1.90
J 6839	Driver	40	8.50
J 6840-01	Gauge	73	5.85
J 6843	Plier Set	*	15.85
J 6844	Tap Set	*	71.30
J 6845	Aligning Gauge	49	28.40
J 6848	Wrench	79	2.15
J 6850	Gauge	40	2.55
J 6851	Remover & Installer Set	*	55.10
J 6852	Remover & Installer	*	63.00
J 6853	Adapter	3-28-84	29.15
J 6855	Fixture	14	8.80
J 6856	Wrench	79	3.15
J 6857	Wrench	79	3.85
J 6858	Adapter Disc Set	o	191.65
J 6865	Adapter	*	2.35
J 6866	Gauge Set	16-18	12.00
J 6868	Fixture	*	57.50
J 6870	Gauge Set	16-18	11.90
J 6874	Spring Compressor	69	34.55
J 6880	Stud Installer	8	2.70
J 6881	Valve Adapter	73	2.90
J 6882	Nut Wrench	*	7.25
J 6885	Holding Fixture	73	47.85
J 6888	Remover and Replacer	73	1.95
J 6889	Guide Pin Set	*	3.00
J 6892	Flaring Kit	81	42.10
J 6893	Nut Wrench	o	11.70
J 6896	Reamer	*	5.80
J 6897	Seal Protector	*	14.95
J 6901	Remover and Replacer	11-23	18.40
J 6902	Remover and Installer	*	4.90

Tool No.	Description	Page No.	Suggested Dealer Price
J 6905	Burnisher	*	15.70
J 6906	Burnisher	*	12.45
J 6907	Burnisher	*	12.45
J 6908	Rethread	*	36.75
J 6909	Rethread	*	39.90
J 6910	Rethread	*	53.55
J 6911	Burnisher	*	12.05
J 6912	Wheel Puller Set	*	24.60
J 6913	Sleeve Puller	*	115.10
J 6914	Block	*	20.75
J 6915	Driver	*	6.55
J 6916	Driver	*	6.55
J 6917	Driver	*	6.55
J 6918	Driver	*	6.55
J 6919	Arm Puller	*	19.75
J 6920	Arm Puller	*	21.50
J 6921	Rethreading Die	*	33.85
J 6922	Staking Tool	*	9.90
J 6923	Wrench Extension	*	4.00
J 6924	Wrench Extension	*	5.75
J 6925	Reamer Set	*	32.25
J 6926	Ring Expander	*	9.30
J 6927	Ring Expander	*	2.95
J 6929	Reamer Set	*	11.65
J 6930	Guide Reamer	*	3.90
J 6931	Pin Remover	*	4.35
J 6932	Threading Die	*	58.15
J 6933	Oil Pump Tool Set	*	14.80
J 6934	Arm Puller	*	21.50
J 6935	Brush Set	*	9.30
J 6936	Riveting Fixture	*	209.50
J 6938	Staking Tool	*	9.90
J 6939	Reamer	*	8.20
J 6940	Ear Puller	*	29.65
J 6941	Gear Replacer	*	5.80
J 6942	Centering Gauge	*	7.50
J 6943	Oil Seal Replace	*	6.25
J 6944	Cap Remover	*	7.20
J 6945	Oil Seal Compressor	*	15.95
J 6946	Seal Installer	*	2.75
J 6947	Guide Replacer	*	3.50
J 6948	Remover and Replacer	*	99.00
J 6949	Core Plug Installer Tool	*	5.75
J 6950	Wrench	*	3.25
J 6951	Gauge Set	*	21.00
J 6952	Adjusting Tool	*	1.45
J 6953	Pilot Removing	*	20.00
J 6954	Carb Tool Set	*	18.85
J 6955	Arbor	*	14.40
J 6956	Spanner Wrench	o	6.95
J 6957	Gauge Set	*	8.00
J 6958	Rear Engine Support	*	13.30

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 6959	Reamer Set	*	26.90
J 6960	Stripping Set	*	14.75
J 6961	Installer	*	66.95
J 6962	Carb Tool Kit	*	15.10
J 6964	Installer	42	13.80
J 6965	Seal Remover	42	10.70
J 6966	Riveting Set	70	18.65
J 6968	Wrench	79	2.85
J 6969	Gauge Set	*	314.75
J 6970	Disc Set	*	209.15
J 6978	Remover	11	18.20
J 6983	Scales	*	9.25
J 6985	Wrench Set	*	155.45
J 6991	Bore Plug	3	6.95
J 6994	Remover and Installer	11-23	16.70
J 6995	Nut Wrench	*	9.90
J 6996	Remover	*	21.95
J 6997	Gauge	49	27.75
J 6999	Holding Fixture	*	5.95
J 7000	Injector Test Set	*	185.80
J 7001	Guide Pins	42	.75
J 7003	Guide Pin	42	.75
J 7004	Remover	42	6.40
J 7005	Remover	42	15.35
J 7006	Oil Seal Installer	42	9.25
J 7007	Assembly Tool	42	1.80
J 7009	Holding Fixture	42	29.75
J 7012	Spacer	43	3.80
J 7013	Bearing Driver Set	43	14.95
J 7017	Oil Seal Installer	65	4.50
J 7022	Remover and Replacer	68	12.05
J 7023	Installer	61	3.25
J 7026	Oil Seal Installer	36	16.50
J 7027	Support	36	1.30
J 7028	Remover	23-55	11.95
J 7031	Remover	*	23.75
J 7032	Installer	*	7.25
J 7034	Gauge	14	3.85
J 7035	Tube	72	2.75
J 7040	Grinder Set	*	252.50
J 7041	Comparator	*	837.50
J 7042	Grinder Set	*	40.95
J 7043	Adapter Set	*	40.65
J 7045	Installer	*	4.95
J 7046	Installer Set	*	8.95
J 7047	Installer	*	4.90
J 7049	Reamer Set	9	50.90
J 7051	Injector Test Set	*	157.80
J 7051-1	Adapter Set	*	16.80
J 7052	Remover and Installer	68	17.00
J 7053	Remover and Installer	58	13.35
J 7055	Bushing Installer	58	13.95
J 7058	Remover	*	30.15
J 7059	Remover	*	29.40
J 7060	Inserter	*	26.95
J 7061	Inserter	*	29.75
J 7062	Inserter	*	32.50
J 7063	Shaft Remover	58	6.40
J 7065	Test Assembly	73	12.40
J 7067	Wrench	*	5.70
J 7068	Gauge Kit	43	33.75
J 7071	Test Set	*	155.80
J 7071-1	Adapter Set	*	14.80
J 7073	Checking Set	36	3.05
J 7076	Gauge	17	.85
J 7077	Support	43	3.45
J 7079	Installer	73	6.35
J 7080	Installer	73	10.05
J 7081	Compressor	73	3.40
J 7085	Remover	73	2.20
J 7086	Assembly Tool	43	2.80
J 7092	Driver	*	4.95
J 7093	Driver	*	3.35
J 7094	Installer	*	6.90
J 7095	Installer	*	6.90
J 7096	Installer	*	8.85
J 7099	Resistor	84-86	9.45
J 7100	Compressor	43	2.65
J 7110	Injector Test Set	*	154.20
J 7110-1	Adapter Set	*	13.20
J 7111	Seal Installer	66	3.10
J 7112	Side Bearing Remover	55	22.60
J 7116	Gauge	43	1.30
J 7117	J 8022 Expander	11	4.35
J 7119	Gauge	49	25.00
J 7120	Bearing Cup Installer	71	4.00
J 7125	Hose Assembly	*	9.95
J 7126	Nut Wrench	*	3.55
J 7132	Protector & Installer	66	5.35
J 7133	Installer	61	4.70
J 7135	Expander	12	4.35
J 7137	Bearing Cup Installer	71	6.30
J 7141	Adapter	66	.70
J 7142	Driver Set	25-36	58.75
J 7143	Line and Fitting	73	5.50
J 7145	Reamer	*	5.95
J 7146	Gauge	73	5.90
J 7147	Remover and Installer	43	4.45
J 7148	Gauge Set	73	3.75
J 7150	Adapter	40	2.50
J 7151-01	Gauge	79	3.75
J 7152	Gauge Set	15	3.05
J 7153	Rotor Aligner	73	3.25
J 7154-01	Installer	75	8.05

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 7156	Gauge Set	73	4.75
J 7157	Gauge	17	.80
J 7158	Socket	75	1.95
J 7159	Socket	75	1.95
J 7160	Clip Pliers	75	3.75
J 7161	Gauge	73	7.70
J 7165	Tool Set	*	16.80
J 7166	Replacer	68	5.50
J 7167	Spreader	68	15.75
J 7169	Valve Gauge	16	1.00
J 7170	Bearing Cup Installer	61	4.95
J 7171	Seal Installer	61	4.50
J 7172	Conversion Set	40	3.50
J 7174	Tool	*	3.45
J 7175	Nozzle Tester	*	102.90
J 7176	Nozzle Tester	*	108.85
J 7177	Crimping Block	73	3.95
J 7179	Replacer	68	4.75
J 7180	Remover and Installer	46	10.80
J 7182-2	Bending Tool	18	2.75
J 7184-01	Monox Hose	27	20.60
J 7184-1	Adapter	84	.75
J 7185-01	Monoxivent	27-84	23.50
J 7187	Compressor	*	3.85
J 7190	Installer	*	4.20
J 7191	Installation Set	*	12.50
J 7192	Installation Tool	*	1.45
J 7196	Gauge Set	15	3.10
J 7273	Service Tool Set	25-43	60.75
J 7277	Gauge	31	3.95
J 7282	Driver Set	55	18.00
J 7285	Installer	14	3.25
J 7287	Gauge	31	4.95
J 7289	Gauge	3	3.90
J 7290	Installer	12	7.50
J 7292	Gauge Set	15	1.65
J 7293	Gauge Set	15	2.85
J 7296	Remover	46	12.15
J 7297	Installer	*	5.75
J 7299	Supporting Blocks	68	8.60
J 7315	Supporting Blocks	68	6.10
J 7317	Removing & Installing Set	*	65.85
J 7320	Gauge Set	15	2.35
J 7323	Gauge Set	15	2.85
J 7325	Gauge Set	15	2.85
J 7326	Gauge Set	15	1.85
J 7327	Gauge Set	15	3.30
J 7328	Gauge Set	15	3.05
J 7329	Overhaul Stand	*	365.00
J 7330	Gauge Set	15	3.45
J 7331	Gauge	17	.80
J 7333	Test Kit	*	365.00
J 7334	Gauge Pkg	*	70.00
J 7341	Nut Wrench	o	12.25
J 7357	Gauge Set	15	2.10
J 7358	Gauge Set	15	†
J 7376	Gauge Set	15	3.30
J 7377	Gauge Set	15	3.20
J 7378	Gauge Set	15	2.85
J 7390	Monoxivent	85	49.10
J 7391	Gauge	15	1.85
J 7395	Removing & Installing Set	*	181.90
J 7400	Gauge Set	15	3.10
J 7401	Gauge Set	15	2.90
J 7402	Gauge Set	15	1.40
J 7403	Gauge Set	15	2.50
J 7405	Gauge Set	15	1.90
J 7406	Gauge	15	1.40
J 7407	Gauge Set	15	2.90
J 7408	Gauge Set	15	3.70
J 7409	Gauge Set	15	2.85
J 7410	Gauge Set	15	2.35
J 7415	Gauge Set	15	2.70
J 7426	Installer	55	4.25
J 7435	Music Wire	*	.50
J 7445	Gauge Set	16-18	27.60
J 7445-1	Gauge	17	.50
J 7447	Gauge Set	o	1.60
J 7450	Gauge Set	o	2.50
J 7477	Gauge Set	15	1.50
J 7478	Gauge Set	15	2.10
J 7479	Gauge Set	15	2.90
J 7504	Gauge Set	15	1.55
J 7536	Gauge Set	15	1.50
J 7564	Gauge Set	15	2.85
J 7568	Light	87	30.00
J 7569	Gauge	87	25.00
J 7570	Gauge	87	9.75
J 7571	Tester	87	54.50
J 7572	Tester	87	5.50
J 8000	KMO 3-A Cutter	81	4.35
J 8001	KMO 30 Dial Indicator	81	27.85
J 8002	KMO 145 Clamps	72	2.20
J 8003	J 129-3 Guide	9	3.95
J 8004	KMO 187-1 Wrench	3	3.25
J 8007	KMO 226-1 Reamer	*	7.95
J 8008	KMO 226-2 Reamer	*	9.05
J 8009	KMO 230 Cleaner	19	.95
J 8010	KMO 242 A Socket	12	1.75
J 8011	Gauge Set	16-18	22.20
J 8014	KMO 297B Rem Repl	12	2.95
J 8015	KMO 297C Rem Repl	12	2.95
J 8016	KMO 297D Rem Repl	12	2.95
J 8017	KMO 297E Rem Repl	12	2.95

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 8018	KMO 297F Remover	12	2.95
J 8020	KMO 297H Ring Tool	12	2.95
J 8021	KMO 297I Rem Repl	12	2.95
J 8022	KMO 297J Rem Repl	*	9.30
J 8023	KMO 297K Rem Repl	*	9.30
J 8028	KMO 297O Rem Repl	12	2.95
J 8029	KMO 297R Rem Repl	12	2.95
J 8030	KMO 297S Expander	*	9.30
J 8031	KMO 297T Expander	*	9.30
J 8032	KMO 297V Ring Ex	12	4.30
J 8033	KMO 312-1 Reamer	*	7.80
J 8034	KMO 312-2 Reamer	*	9.55
J 8037	KMO 357 Inserter	12	2.50
J 8039	KMO 410 Pliers	*	4.25
J 8041	KMO 449A Screw Driver	75	5.40
J 8047	KMO 505 Brush	20	2.30
J 8048	KMO 506A Reg Kit	20	12.65
J 8049	KMO 526A Rem Repl	72	2.75
J 8050	J 2185 A Tool Set	82	72.65
J 8051	2185 B Tool Set	72-82	58.50
J 8052	KMO 570 Wrench	71	2.25
J 8053	KMO 584 Ring Com	13	2.70
J 8054	KMO 585 Ring Com	13	2.70
J 8055	KMO 598A Detector	3	12.50
J 8056	KMO 607 Tester	9	26.05
J 8057	KMO 621 Pliers	72	3.05
J 8058	KMO 629 Wrench	82	12.35
J 8059	KMO 630 Pliers	82	5.70
J 8060	KMO 631 Gauge	*	26.00
J 8062	KMO 642 Lifter	*	10.75
J 8063	KMO 643 Aligner	20	5.30
J 8064	KMO 644 Press	*	58.00
J 8068	KMO 653 Adapter	82	1.35
J 8069	KMO 654 A Reamer	*	12.80
J 8071	KMO 671 Cutter	75	5.95
J 8074	KMO 687 Gauge	79	12.00
J 8075	KMO 692 Adapter	82	1.45
J 8076	KMO 695 Adjusting Bit	61	2.50
J 8079	KMO 712 Compressor	13	2.50
J 8080	KMO 734 Remover	3	1.90
J 8081	KMO 735 Compressor	70	14.95
J 8087	KMO 913 Gauge	3	29.45
J 8089	KMO 7004 Brush	3	1.70
J 8091	J 872-3A Set Tool	*	10.95
J 8092	J 872-5 Handle	82	3.40
J 8093	J 872-4 Replacer	*	6.95
J 8095	J 1376H Puller	*	11.85
J 8096	5759 Blower 1 PH	85	146.50
J 8097	J 5760 Blower 1 PH	85	174.50
J 8098	5761 Blower 1 PH	85	261.50
J 8099	J 5762A Blower	85	342.50
J 8100	J 5762B Blower	85	387.65
J 8101	KMO 122 Cleaner	9	1.50
J 8102	KMO-18711 Adapter	*	1.00
J 8105	T 126 RA Puller	13	9.45
J 8106	PR 131 Reamer	9	6.35
J 8107	TR 278 R Puller	*	12.75
J-8107-2	TR 278 R2 Washer	55	1.80
J 8108	K 342 Press Plate	*	5.20
J 8109	K 353 Wrench	*	10.85
J 8111	HM 925 Puller	82	33.75
J 8113	K 318 Rem & Repl	*	3.95
J 8114	J 872-1 Replacer	*	6.50
J 8117	J 1436-8 Adapter	43-59	2.90
J 8118	J 1436-9 Puller	*	3.95
J 8119	J 1436-10 Remover	59	13.50
J 8124	J 4353-1 Assy	*	4.70
J 8124-01	Blow Gun Assembly	36	5.55
J 8127	KMO 112 Tool Set	20-82	8.90
J 8128	KMO 232 Assembly Tool	*	1.75
J 8129	HM593-1 Scale	82	6.90
J 8131	J 942-1 Puller	22-59	6.50
J 8139	J 5737-6 Plate	23-55-87	4.80
J 8140	J 5737-7 Washer	23-56	1.50
J 8142	KMO 287 W Rem Repl	13	4.30
J 8147	J 1682BA Tool Set	*	34.30
J 8148	Inserter	71	3.80
J 8149	Inserter	71	3.95
J 8150	KMO 237 Brush	*	.25
J 8151	KMO 320A Gauge	*	7.50
J 8152	KMO 236 Brush	*	.35
J 8153	KMO 884 Manometer	*	17.30
J 8156	J 3955 A Fixture	20	33.95
J 8157	1298NA Remover	31	24.60
J 8158	KMO 890 Ext Arms	*	6.75
J 8159	KMO 891 Ext Arm	*	6.75
J 8160	KMO 892 Ext Arm	*	6.75
J 8161	KMO 893 Ext Arm	*	6.75
J 8162	KMO 894 Ext Arm	*	6.75
J 8165	Grinder	*	280.00
J 8166	KMO 889 Meter	*	45.00
J 8167	KMO 886 Gauge	*	20.50
J 8168	KMO 233 Gauge	*	.50
J 8169	KMO 235 Cleaner	*	1.60
J 8170	KMO 238 Stone	*	.45
J 8171	KMO 926 Legs	*	8.95
J 8172	KMO 461 Rule	*	.20
J 8173	KMO 863 Puller	*	9.90
J 8174	KMO 864 Puller	*	19.30
J 8175	KMO 865 Puller	*	29.95
J 8176	KMO 866 Separator	*	19.95
J 8177	KMO 867 Puller	*	17.95
J 8178	KMO 868 Puller	*	18.10

* Illustrated in Industrial Catalog - Form No. 58-12

† Discontinued

o Not Illustrated

Tool No.	Description	Page No.	Suggested Dealer Price
J 8179	KMO 869 Puller	*	29.55
J 8180	KMO 870 Legs	*	5.95
J 8181	KMO 871 Adapter	*	3.00
J 8182	KMO 872 Adapter	*	3.00
J 8183	KMO 873 Adapters	*	3.00
J 8184	KMO 874 Adapters	*	3.00
J 8186	KMO 876 Manometer	*	11.75
J 8187	KMO 877 Manometer	*	14.50
J 8188	KMO 878 Manometer	*	16.00
J 8189	KMO 885 Gauge	*	20.50
J 8190	KMO 887 Puller	*	28.95
J 8191	KMO 888 Pet Cock	*	1.00
J 8192	KMO 895 Arm	*	6.75
J 8194	J 2241 B Remover	56	16.65
J 8196	Mt Plate	*	57.00
J 8198	J 4979-1 Template	*	48.50
J 8200-01	J 4265-13 Adapter	*	77.75
J 8201	J 4209 Inst Kit	*	246.60
J 8202	J 4209A Test Kit	*	243.35
J 8203	J 4209B Test Kit	*	254.15
J 8204	J 4209C Test Kit	*	273.60
J 8205	J 4209D Test Kit	*	274.00
J 8210	Choke Gauge	16	1.30
J 8212	Wire Gauge	16	.80
J 8213	Wire Gauge	16	.80
J 8214	Wire Gauge	16	.60
J 8215	Float Gauge	17	.80
J 8216	Float Gauge	17	.50
J 8217	Float Gauge	17	.50
J 8218	Spec. Screw Holder	18	.50
J 8219	Jet Wrench	18	1.85
J 8220	Remover	18	1.60
J 8221	Wrench	18	.55
J 8222	Driver	18	1.30
J 8223	Socket	18	.75
J 8224	Remover	18	1.70
J 8225	Remover	18	.90
J 8226	Wrench	18	1.05
J 8227	Lead Ball Set	18	.65
J 10167-1	Palm Grip	43	1.70
J 10167-3	Palm Grip	43	2.05
J 10174	Jet Tool	18	2.25
J 10175	Valve Tool	18	1.20
J 10192	Float Gauge	17	1.25
S 1055	Retainer	31	1.55
S 1124	Nut Wrench	56	4.15
SW 91	Seal Installer	59	4.85
SW 97	Remover	56	11.95
SW 225	Installer	56	9.30

State and local sales and/or use tax will be added to order if applicable.

KENT-MOORE

ORGANIZATION, INC.

Engineers and Manufacturers of Automotive Service Tools and Equipment

Executive Offices: 28635 Mound Road • Warren, Michigan
Factories and General Offices: Jackson, Michigan

Form No. 58-39

Litho in U.S.A.

* Illustrated in Industrial Catalog - Form No. 58-12
† Discontinued
o Not Illustrated